



Magnetic Particle Inspection

Product information MR[®] 158-R GF Magnetic powder suspension



MR® 158-R GF Magnetic powder suspension

fluorescent, ready for use for Magnetic Particle Inspection acc. to EN ISO 9934-1

General appearance and composition:

- · Magnetic powder suspension with fluorescent ferromagnetic particles
- High sensitivity
- · Includes corrosion inhibitor and other additives
- Free of nitrite, halogen, sulphur and silicone
- Medium particle size d_a = 1-3 μm
- Yellow-green fluorescent under UV-radiation
- VOC-contents < 0,1 %
- No flammable propellants, but compressed air
- Aersol over head sprayable
- No unpleasant odour
- Water based
- Sediment 0,20 0,30 ml / 100 ml (1/2 h) (corresponds with ASTM E 14444)
- Processing temperature +10 °C and +50 °C
- No declaration of hazardous ingredients ECO-LINE

Relevant Specifications

The product is based on MR^{\otimes} 158-R magnetic powder concentrate. For this the following permissions are available:

- Type testing in accordance to DIN EN ISO 9934 part 2
- The corrosive components of MR[®] 158-R are in accordance with EN ISO 9934-2
- In correspondence with Lloyd's Reg., Bureau Veritas, Det Norske Veritas, admitted by Framatome ANP

Application:

- Remove tinder, rust and other contaminations from surface in a suitable manner. (e.g. with MR[®] 71 Paint Remover)
- Shake suspension and aerosol can well.
- That is required to mix the contents sufficiently.
- \bullet During magnetization (e.g. with a MR $^{\! 8}$ Hand yoke) spray MR $^{\! 8}$ 158-R GF Magnetic powder suspension on the surface.
- If using a test bench, fill the preparation into the container with the pump.
- Under UV-radiation discontinuities will appear as yellow-green fluorescent magnetic particle indications.

Minimum shelf life:

- Aerosols and bulks will keep for a minimum of 1 year
- Protect against frost!
- Storage temperature 5-30 °C

Pack sizes:

- Aerosols 300 g (active substance!)
- 5 kg, 10 kg
- → The advantage of aerosols with the propellant compressed-air is that at a net product volume of 300 ml they contain approx. 30-40 % more usable test medium than a 500 ml aerosol with propellant propane/butane.

07.11.2014/db

Technical changes reserved!